



BMW R 1200 ST

Schutzbügel Montagehinweise

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTECH gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

| | |
|-----|--------|
| M6 | 9,6 Nm |
| M8 | 23 Nm |
| M10 | 46 Nm |

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben.

Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

SW-MOTECH GmbH & Co. KG
Bahnhofstrasse 44d
35282 Rauschenberg
-Germany-

Tel.: ++ 49 (0) 6425 816 800
Fax: ++ 49 (0) 6425 816 810

www.sw-motech.com

Crash Bar Mounting Instructions

SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW-MOTECH takes no responsibility for damages caused by improper installation.

All screws, bolts and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

| | |
|-----|--------|
| M6 | 9,6 Nm |
| M8 | 23 Nm |
| M10 | 46 Nm |


All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts and nuts.

! Achtung: die Schräglagenfreiheit kann durch den Schutzbügel reduziert werden!

Attention: the lean angle can be reduced by the crash bar!

1 Schutzbügel
Crash Bar




SBL.07.551.901/902 **00**
Anzahl/ Pcs. 2 (L/R)

4 Innensechskantschraube
Hexagon Socket Screw




M12 x 80 DIN 912
Anzahl/ Pcs. 2

7 Klemmschelle
Clamp




schwarz/silber
SBL.00.051.002 **01**
Anzahl/ Pcs. 1

2 Innensechskantschraube
Hexagon Socket Screw




M12 x 260 DIN 912
Anzahl/ Pcs. 1

5 Unterlegscheibe
Washer




A: 13 DIN 125
Anzahl/ Pcs. 3

8 Innensechskantschraube
Hexagon Socket Screw




M6 x 20 DIN 912
Anzahl/ Pcs. 2

3 Distanzbuchse
Spacer




Da:25 Di:12,5 h:15
Anzahl/ Pcs. 2

6 Distanzbuchse
Spacer




Da:25 Di:12,5 h:25
Anzahl/ Pcs. 2

9 Mutter, selbstsichernd
Lock Nut



M6 DIN 985
Anzahl/ Pcs. 2


! Original Mutter verwenden.
Use the original nut.



- 3
- 1
- 5
- 2

- 7
- 8
- 9

- 5
- 4
- 6



Fahrtrichtung
Driving direction

Linke Seite/left side

