

Lista de modelos para **DISC 305x181x4,8**

Modelo

BMW - 850 - R 850 C - 1998 / 2001 - MOTO - FRONT - L/R - -
BMW - 850 - R 850 GS - 1998 / 2007 - MOTO - FRONT - L/R - -
BMW - 850 - R 850 R - 2002 / 2007 - MOTO - FRONT - L/R - -
BMW - 1100 - R 1100 GS - 1994 / 2001 - MOTO - FRONT - L/R - -
BMW - 1100 - R 1100 R (SPOKES WHEELS) - 1993 / 2001 - MOTO - FRONT - L/R - -
BMW - 1100 - R 1100 RT (SPOKES WHEELS) - 1993 / 2003 - MOTO - FRONT - L/R - -
BMW - 1100 - R 1100 S - 1998 / 2000 - MOTO - FRONT - L/R - -
BMW - 1150 - R 1150 GS - 1999 / 2001 - MOTO - FRONT - L/R - -
BMW - 1150 - R 1150 GS ADVENTURE - 2002 / 2005 - MOTO - FRONT - L/R - -
BMW - 1200 - HP 2 1200 - 2006 / 2010 - MOTO - FRONT - L/R - -
BMW - 1200 - K 1200 LT - 1999 / 2000 - MOTO - FRONT - L/R - -
BMW - 1200 - K 1200 RS - 1997 / 2000 - MOTO - FRONT - L/R - -
BMW - 1200 - R 1200 C - 1998 / 2000 - MOTO - FRONT - L/R - -
BMW - 1200 - R 1200 C "CRUISER" - 1997 / 2001 - MOTO - FRONT - L/R - -
BMW - 1200 - R 1200 C CLASSIC - 2003 - MOTO - FRONT - L/R - -
BMW - 1200 - R 1200 CL - 2002 / 2006 - MOTO - FRONT - L/R - -
BMW - 1200 - R GS / GS ADVENTURE / ABS - 2008 / 2012 - MOTO - FRONT - L/R - -